

How to upload software from PC to the Supersat receiver

1- download Loader_V31 and the latest update file from our [download page](#)

2- Connect the receiver to the PC with a DB9 NULL MODEM cable. and connect the the receiver to the power and power it on from the back switch.

3- Double click the icon of the Loader v31 on your PC desk top.




Loader_V32

4- the loader will automatically find the PC port were the receiver is connected and will display **Connected** and the name of the port. (most of the time is **COM1**)

if not just Click **FIND CONNECTION** button and the loader will find the port.



5- Click the File button and Select the file that you want to Upload.



6- press the **Start** button on the loader.

First Flash memory And old software will be erased. Then the new software will be loaded.



7- When the download is complete a message will display download complete.

